



ASSA ABLOY

# PERIMETER GASKETING

Applies to the following products:

303\_S, 303\_PK, 316\_S, 316\_PK, 297\_PK, 297\_S, 375\_R

## Testing/Ratings:




**BHMA**  
CERTIFIED



Category J gaskets for use with listed steel frames and/or classified steel covered composite, hollow metal doors rated up to and including 3 hours; wood and plastic covered composite doors rated up to and including 1-1/2 hours; and wood core doors rated for 20 minutes.

## Tools Required:



## Installation Instructions:

### PERIMETER GASKETING:

Please note: This package contains 1 short (header) piece and 2 long (jamb) pieces of weatherstrip. For ease of installation, install header piece first, then 2 jamb pieces.

1. Can be installed on a wood or metal frame.
2. Measure, mark and trim header piece to length. Close door and position header piece on header stop so that seal makes light even contact with door. Mark header stop in center of slotted holes.
3. Drill pilot holes in header stop at marks.
4. Secure header piece to header stop with supplied screws.
5. To install the 2 jamb pieces, repeat steps 2, 3, and 4. Jamb pieces should contact threshold (or floor) at bottom & contact header piece at top.
6. Open and close door several times to check jamb weatherstrip fit and seal, and to make sure latch bolt engages strike plate.
7. To adjust, loosen screws, re-position weatherstrip, and tighten screws.

### ASTRAGALS/MEETING STILES:

1. Trim lengths equal to door height.
2. Position at meeting stile edge of doors. Install screws in center of slots.
3. Adjust as required for proper seal, with ease of opening and closing, then tighten screws.

[www.pemko.com](http://www.pemko.com)

© 2009 Pemko Manufacturing Co.  
PG1\_WEBINS  
Rev 1 - 07.22.09